

## TRIO トリオ




重量:2.4kg(脚は除く)

## トリオ

選地ランク (脚部価格に含まれません)

- A 23,900
- B 26,000
- C 29,000
- D 29,700
- S 34,500
- L 39,500
- H 45,400

レザー-A-R0 (No.90)  
脚-KS-CR

## LOMAN ロマン




重量:2.2kg(脚は除く)

## ロマン

選地ランク (脚部価格に含まれません)

- A 27,900
- B 29,700
- C 33,500
- D 34,600
- S 40,600
- L 46,800
- H 54,100

レザー-A-R0 (No.82)  
脚-KS-CR

## NANCAY ナンセ




重量:2.5kg(脚は除く)

## ナンセ

選地ランク (脚部価格に含まれません)


- A 27,500
- B 29,700
- C 34,200
- D 34,700
- S 41,500
- L 47,800
- H 54,100

レザー-A-R0 (No.42)  
脚-KS-BL

## ナンセ K

選地ランク (脚部価格に含まれません)

- A 28,600
- B 31,600
- C 35,800
- D 36,200
- S 43,400
- L 49,200
- H 55,500

レザー-A-R0 (No.85)  
脚-KS-BL

## PICASSO ピカソ




重量:2.3kg(脚は除く)

## ピカソ

選地ランク (脚部価格に含まれません)


- A 25,100
- B 27,100
- C 30,600
- D 31,300
- S 37,000
- L 42,400
- H 48,100

レザー-A-R0 (No.75)  
脚-KS-CR

## ピカソ K

選地ランク (脚部価格に含まれません)

- A 27,400
- B 29,400
- C 32,800
- D 33,400
- S 39,300
- L 44,700
- H 50,400

レザー-A-R0 (No.24)  
脚-KS-CR